



1




For your safety unplug the machine.

2



Open face cover using driver.

3




Remove the bulb by unscrewing it in a counterclockwise direction.

4



Réf : 150048-116
Install a new bulb.


5



Replace face cover by turning screw clockwise.

6

7



Plug in your machine and switch on power to test the bulb.